



REF.	Code	Description
1	3000221	INSERTO PER PIANO INF. INSERT FOR LOWER PANEL • INSERT POUR PLAN INF. • INSERTO PARA PLANO INF.
2	3000279	VOLANTINO INCLIN. TESTA TILT HEAD FLYER • VOLANT INCLIN. TÊTE • VOLANTE INCL. CABEZA
3	3000282	PROTEZIONE LAMA SUP. BLADE PROTECTION SUP. • PROTECTION LAME SUP. • PROTECCIÓN CUCHILLA SUP.
4	3000283	PROTEZIONE LAMA AMOVIB. REMOVABLE BLADE GUARD • PROTECTION LAME AMOV. • PROTECCIÓN CUCHILLA DESMONT.
5	3000284	LEVA-MICRO-ASSE-POMELLO MICRO-LEVER-SHAFT-KNOB • LEVIER-MICRO-AXE-BOUTON • PALANCA-MICRO-EJE-POMO
6	3000285	INSERTO PIANO SUP. TOP INSERT • INSERT PLAT SUP. • INSERTO PLANO SUP.
7	3000288	SCOCCA LATERALE SX LEFT SIDE SHELL • COQUE LATÉRALE GAUCHE • CARCASA LATERAL IZQ
8	3200476	MANOPOLA FISSA PIANO FIXED KNOB FLAT • BOUTON FIXE PLAN • MANDO FIJO PLANO
9	5051097	FLANGE FISSALAMA FIXED FLANGE • BRIDE FIXALAMA • BRIDA FIJALAMA
11	5300475	VOLANTINO BLOCCA PIANO SUP. SUP. PLANE LOCK KNOB • VOLANT DE BLOCAGE PLAN SUP. • VOLANTE BLOQUEA PLANO SUP.
12	5300482	PROTEZIONE LAMA E LEVE BLADE & LEVER PROTECTION • PROTECTION LAME ET LEVIERS • PROTECCIÓN CUCHILLA Y PALANCAS
13	5300483	RIDUTTORE REDUCER • RÉDUCTEUR • REDUCTOR
14	5300484	PIANO LAVORO SUP. WORK PLAN SUP. • PLAN DE TRAVAIL SUP. • PLAN TRABAJO SUP.
15	5300485	GUIDA PEZZO PART GUIDE • GUIDE PIÈCE • GUÍA PIEZA
16	5300486	SUPPORTO SNODATO SWIVEL SUPPORT • SUPPORT ARTICULÉ • SOPORTE ARTICULADO
17	5951126	GUIDAPEZZO WORKPIECE GUIDE • GUIDEPIÈCE • GUÍAPIEZAS
19	7250324	SPAZZOLE E PORTASPAZZOLE BRUSHES & BRUSH HOLDERS • BROSSES ET PORTE-BROSSES • CEPILLOS Y PORTACEPILLOS
20	7356103	STATORE STATOR • STATOR • ESTATOR
21	7356104	ROTORE ROTOR • ROTOR • ROTOR



REF.	Code	Description
22	7357577	INTERRUTTORE TRONCATRICE MITER SAW SWITCH • INTERRUPTEUR TRONÇONNEUSE • INTERRUPTOR TRONZADORA
23	7400722	INTER. MAGNETICO BANCO SEGA MAGNETIC TABLE SAW SWITCH • INT. MAGNÉTIQUE SCIE TABLE • INT. MAGNÉTICO BANCO SIERRA