




# SEGA A NASTRO SN 208D 8"

WOOD BAND SAW SN208D 8" • SCIE A RUBAN SN 208D 8" •  
SIERRA DE CINTA SN 208D 8"

Spare Parts

Art.nr. : 1410149





REF.	Code	Description
1	3200505	COPPIA ANELLI PULEGGE PULLEY RING PAIR • PAIRE D'ANNEAU DE POULIE • PAR DE ANILLOS DE POLEA
2	5001573	PULEGGIA SUPERIORE UPPER PULLEY • POULIE SUPÉRIEURE • POLEA SUPERIOR
3	5001574	PULEGGIA MOTORE PULLEY MOTOR • POULIE MOTEUR • POLEA DEL MOTOR
4	7350734	INTERRUTTORE SWITCH • CHANGER • CAMBIAR
5	3200504	VOLANTINI TENDILAMA-INCLINAZ. KNOBS • TRACTS • FOLLETOS
6	5001570	GUIDALAMA INFERIORE LOWER SHEET GUIDE • GUIDE DE LAME INFÉRIEUR • GUÍA INFERIOR DE CUCHILLA
7	5001572	GUIDA TAGLIO E GONIOMETRO CUTTING GUIDE & PROTRACTOR • GUIDE DE COUPE ET RAPPORTEUR • GUÍA DE CORTE Y TRANSPORTADOR
8	3200502	INSERTO PIANO LAVORO INSERT • INSERTION PLAN DE TRAVAIL • INSERTO DE ENCIMERA
9	7350735	MOTORE ELECTRIC MOTOR • MOTEUR • MOTOR
10	3200503	2 SPORTELLI 2 DOORS • 2 PORTES • 2 PUERTAS
11	5001575	GUIDALAMA SUPUPERIORE UPPER BLADE GUIDE • GUIDE-LAME SUP. • GUÍALAMA SUP.
12	5001571	PIANO LAVORO COMPLETO FULL WORKTABLE • TABLE DE TRAVAIL COMPLÈTE • MESA DE TRABAJO COMPLETA
13	3200508	4 GOMMINI ANTIVIBRANTI 4 ANTI-VIBRATION RUBBERS • 4 CAOUTCHOUC ANTI-VIBRATION • 4 GOMA ANTIVIBRACIONES