



REF.	Code	Description
1	3000265	SCATOLA INTERRUOTORE SWITCH BOX • BOÎTIER INTERRUPTEUR • CAJA INTERRUPTOR
2	3000262	PROTEZ. MANDRINO-MICRO SPINDLE-MICRO PROT. • PROT. MANDRIN-MICRO • PROT. MANDRIL-MICRO
3	5300141	ANELLO GUIDA CREMAGLIERA RACK GUIDE RING • BAGUE GUIDE CRÉMAILLÈRE • ANILLO GUÍA CREMALLERA
4	5010745	LEVA ABBASSAMENTO MANDRINO SPINDLE LOWERING LEVER • LEVIER ABAISSEMENT MANDRIN • PALANCA BAJADA MANDRIL
5	5300097	MANOVELLA CRANK • MANIVELLE • MANIVELA
7	5300142	CONO MORSE MORSE TAPER • CÔNE MORSE • CONO MORSE
8	5300143	COLLARE PIANO LAVORO WORKTOP COLLAR • COLLIER PLAN DE TRAVAIL • COLLAR PLANO TRABAJO
9	5300144	CARTER COPRIPULEGGE PULLEY COVER • CARTER COUVRE-POULIE • CARTER CUBREPOLEA
10	5010737	MANDRINO E CHIAVE CHUCK & KEY • MANDRIN ET CLÉ • MANDRILLO Y LLAVE
11	5300146	CREMAGLIERA RACK • CRÉMAILLÈRE • CREMALLERA
12	5300147	PULEGGIA MOTORE MOTOR PULLEY • POULIE MOTEUR • POLEA MOTOR
13	5300148	PULEGGIA CONDOTTA DRIVEN PULLEY • POULIE MENÉE • POLEA CONDUCTIDA
14	5300149	PULEGGIA DI RINVIO IDLER PULLEY • POULIE DE RENVOI • POLEA DE DESVÍO
15	3000266	COPPIA CINGHIE BELT PAIR • COUPLE COURROIES • PAREJA DE CORREAS
16	5300150	ALBERO PULEGGIA PULLEY SHAFT • ARBRE POULIE • ÁRBOL POLEA
17	5300151	MOLLA RITORNO RETURN SPRING • RESSORT DE RETOUR • MUELLE RETORNO
18	5300152	COLONNA E PIEDE COLUMN & BASE • COLONNE ET PIED • COLUMN Y PIE DE PÁGINA
20	5300154	BASE BASE • BASE • BASE
21	5300155	PIANO LAVORO WORKTOP • PLAN DE TRAVAIL • PLAN TRABAJO



REF.	Code	Description
22	7400670	MOTORE ENGINE • MOTEUR • MOTOR
23	7400671	INTERRUTTORE SWITCH • INTERRUPTEUR • INTERRUPTOR
24	5300156	ALBERO ABBASSAMENTO MANDRINO SPINDLE LOWERING SHAFT • ARBRE ABAISSEMENT BROCHE • ÁRBOL BAJADA HUSILLO
25	7400637	MICRO VANO PULEGGE MICRO PULLEY COMPARTMENT • MICRO COMPARTIMENT POULIES • MICRO ESPACIO POLEAS
26	5300157	ALBERO PORTAMANDRINO SPINDLE SHAFT • ARBRE PORTE-MANDRIN • ÁRBOL PORTAMANDRIL
27	5010633	ECCENTRICO ECCENTRIC • EXCENTRIQUE • EXCÉNTRICO